NOT MEASUREMENT SENSITIVE MIL-PRF-19207F SUPPLEMENT 1 15 May 2007

## PERFORMANCE SPECIFICATION

## FUSEHOLDERS, EXTRACTOR POST TYPE, BLOWN FUSE INDICATING AND NONINDICATING, GENERAL SPECIFICATION FOR

This supplement forms a part of MIL-PRF-19207F, dated 15 May 2007

## **SPECIFICATION SHEETS**

| MIL-PRF-19207/1  | - | Fuseholders, Extractor Post Type, Blown Fuse Indicating, Types FHL10U and FHL10G.        |
|------------------|---|--|
| MIL-PRF-19207/2  | - | Fuseholders, Extractor Post Type, Blown Fuse Indicating, Type FHL11U and FHL11G.         |
| MIL-PRF-19207/3  | - | Fuseholders, Extractor Post Type, Blown Fuse Indicating, Types FHL12U and FHL12G.        |
| MIL-PRF-19207/4  | - | Fuseholders, Extractor Post Type, Blown Fuse Indicating, Type FHL13G.                    |
| MIL-PRF-19207/5  | - | Fuseholders, Extractor Post Type, Blown Fuse Indicating, Type FHL14G.                    |
| MIL-PRF-19207/6  | - | Fuseholders, Extractor Post Type, Blown Fuse Indicating, and Nonindicating, Type FHL15G. |
| MIL-PRF-19207/7  | - | Fuseholders, Extractor Post Type, Blown Fuse Indicating, Type FHL16G.                    |
| MIL-PRF-19207/8  | - | Fuseholders, Extractor Post Type, Blown Fuse Indicating, Types FHL17G1 and FHL17G2.      |
| MIL-PRF-19207/9  | - | Fuseholders, Extractor Post Type, Blown Fuse Indicating, Types FHL18G1 and FHL18G2.      |
| MIL-PRF-19207/10 | - | Fuseholders, Extractor Post Type, Nonindicating, Types FHN19G and FHN19W.                |
| MIL-PRF-19207/11 | - | Fuseholder, Extractor Post Type, Blown Fuse, Nonindicating Type FHN20G.                  |
| MIL-PRF-19207/12 | - | Fuseholders, Extractor Post Type, Blown Fuse Indicating, Type FHL22W.                    |
| MIL-PRF-19207/13 | - | Fuseholders, Extractor Post Type, Nonindicating, Type FHN23W.                            |

AMSC N/A FSC 5920

## MIL-PRF-19207F SUPPLEMENT 1

| MIL-PRF-19207/16 | - | Fuseholders, Extractor Post Type, Nonindicating, Types FHN26G1, FHN26G2, and FHN26W. |
|------------------|---|--|
| MIL-PRF-19207/17 | - | Fuseholders, Extractor Post Type, Nonindicating, Types FHN28W and FHN28WB.           |
| MIL-PRF-19207/18 | - | Fuseholders, Extractor Post Type, Blown Fuse Indicating, Type FHL29G.                |
| MIL-PRF-19207/19 | - | Fuseholders, Extractor Post Type, Blown Fuse Indicating, Type FHL30G.                |
| MIL-PRF-19207/20 | - | Fuseholders, Extractor Post Type, Nonindicating, Types FHN31G1 and FHN31G2.          |
| MIL-PRF-19207/21 | - | Fuseholders, Extractor Post Type, Blown Fuse Indicating, Type FHL32W.                |
| MIL-PRF-19207/22 | - | Fuseholders, Extractor Post Type, Blown Fuse Indicating, Type FHL33W.                |
| MIL-PRF-19207/23 | - | Fuseholders, Extractor Post Type, Blown Fuse Indicating, Type FHL34W.                |
| MIL-PRF-19207/24 | - | Fuseholders, Extractor Post Type, Blown Fuse Indicating, Type FHL35W.                |
| MIL-PRF-19207/25 | - | Fuseholders, Extractor Post Type, Nonindicating, Types FHN41W and FHN41WB.           |
| MIL-PRF-19207/26 | - | Fuseholders, Extractor Post Type, Nonindicating, Type FHN42W.                        |
| MIL-PRF-19207/28 | - | Fuseholders, Extractor Post Type, Blown Fuse Indicating, Type FHL44G.                |
| MIL-PRF-19207/29 | - | Fuseholders, Extractor Post Type, Blown Fuse Indicating, Type FHN45G.                |
| MIL-PRF-19207/30 | - | Fuseholders, Extractor Post Type, Nonindicating, Types FHN46W FHN46WB.               |
| MIL-PRF-19207/31 | - | Fuseholders, Extractor Post Type, Nonindicating, Types FHN47W FHN47WB.               |
| MIL-PRF-19207/36 | - | Fuseholders, Extractor Post Type, Nonindicating, R.F. Shielded Type FHN55W.          |
| MIL-PRF-19207/38 | - | Fuseholders, Extractor Post Type, Blown Fuse Indicating, Type FHL57G.                |
|                  |   |  |

Custodians:

Army - CR Navy - SH Air Force - 11 Preparing activity: DLA - CC

(Project 5920-2006-026)

Review activities:

Army - AR, AT, CR4 MI Navy - AS, EC, MC, OS Air Force - 19, 70, 71, 84, 99

NOTE: the activities listed above were interested in this document as of the date of this document. Since organizations and responsibilities can change, you should verify the currency of the information above using the ASSIST Online database at <a href="http://assist.daps.dla.mil.">http://assist.daps.dla.mil.</a>